


OUTDOOR TENSION X BANNER



Sizes Available 

H 210 x W 80 x D 54

Suitable Media 


Banner Vinyl

ASSEMBLY INSTRUCTIONS

Remove all products from packaging


1

Attach and secure bottom fixing to main vertical pole



2


Insert pole into base and secure



ASSEMBLY INSTRUCTIONS CONTINUED

3

Insert cross poles ensuring they are secured



4

Attach graphic via eyelets and fill base with water

